

China Crusher Wear Parts Procurement Decision & Verification Sheet

One-page reference for procurement, maintenance & reliability teams

How to use: Identify your operating scenario → focus on the related risks → request the matching verification evidence.
Missing evidence indicates mismatched risk.

Step 1 | Operating Scenario Classification

Level A – Cost-driven	Limited runtime, backup machines, acceptable downtime
Level B – Stability-driven	Continuous operation, downtime impacts cost
Level C – Critical	High-load crushing, unplanned downtime unacceptable

Step 2 | Primary Risk by Scenario

Level A	Incorrect fit or part mismatch
Level B	Batch-to-batch performance variation
Level C	Internal defects & unpredictable failure

Step 3 | Verification Requirements

Level A (Minimum Safe Baseline)

- Confirm part number AND 2–3 critical mounting dimensions
- Material type clearly defined
- Basic outgoing inspection (appearance & dimensions)

Level B (Stability-focused)

- Explain part number version/region differences
- Chemical composition ranges & batch consistency logic
- Defined heat treatment & quenching parameter ranges

Level C (Critical risk control)

- 3D scanning or reverse engineering when part numbers are incomplete
- Casting integrity explanation (inclusion, porosity risk reduction)
- Industry-aligned heat treatment (e.g. $\geq 1040^{\circ}\text{C}$ solution treatment for Mn-steel)
- Appropriate inspection records (UT / DPT) & install-ready delivery protection

Final Decision Rule:

Part numbers locate. Drawings define. Critical dimensions verify.

Material sets the baseline. Process controls consistency.

Evidence decides where the risk stays.

Prepared by PAJOA®

China Crusher Wear Parts – Procurement Reference